



Scratch Building Raspberry Pi RP2040 IoT Devices

Day 5:

Coding a Raspberry Pi Pico W ToF Application

Sponsored by



11111111







Webinar Logistics

- Turn on your system sound to hear the streaming presentation.
- If you have technical problems, click "Help" or submit a question asking for assistance.
- Participate in 'Attendee Chat' by maximizing the chat widget in your dock.



Sponsored By





Fred Eady

Visit 'Lecturer Profile' in your console for more details.



Scratch Building Raspberry Pi RP2040 IoT Devices


AGENDA

Sponsored By



Hardware Hookup


The Merge





Sponsored By

M88 ToF Module Hookup






M88 ToF Module Hookup



Sponsored By



M88 ToF Module Hookup






7

CORPORATIO



Sponsored By

M88 ToF Module Hookup





Sponsored By

CMakeLists.txt – Add Executables

M CMa	akeLists.txt							
1	# Set minimum required version of CMake							
2	<pre>cmake_minimum_required(VERSION 3.12)</pre>							
3								
4	# Include build functions from Pico SDK							
5	include(\$ENV{PIC0_SDK_PATH}/external/pico_sdk_import.cmake)							
6								
7	# Set name of project (as PROJECT_NAME) and C/C++ standards							
8	project(tofClient C CXX ASM)							
9	set(CMAKE_C_STANDARD 11)							
10	<pre>set(CMAKE_CXX_STANDARD 17)</pre>							
11								
12	# Creates a pico-sdk subdirectory in our project for the libraries							
13	pico_sdk_init()							
14								
15	if (NOT TEST_TCP_SERVER_IP)							
16	<pre>message("Skipping tcp_client example as TEST_TCP_SERVER_IP is not defined"</pre>							
17	else()							
18	<pre>add_executable(\${PROJECT_NAME}</pre>							
19	tofClient.c							
20	tof.c							
21	M8driver.c							
22								
23								
24	<pre>target_compile_definitions(\${PROJECT_NAME} PRIVATE</pre>							
25	WIFI_SSID=\"\${WIFI_SSID}\"							
26	WIFI_PASSWORD=\"\${WIFI_PASSWORD}\"							
27	TEST_TCP_SERVER_IP=\"\${TEST_TCP_SERVER_IP}\"							
28	target include directories (\$ (DROJECT NAME) DETVATE							
29	<pre>target_include_directories(\${PROJECT_NAME} PRIVATE</pre>							
30	\${CMAKE_CURRENT_LIST_DIR} \${CMAKE_CURRENT_LIST_DIR}/ # for our common lwipopts							
31	\${CHARE_CORRENT_LIST_DIR} # TOT OUT COMMON (WIPOPUS							
32	target link libraries(\${PROJECT NAME}							
33 34	pico cyw43 arch_lwip_poll							
35	pico_cywis_arch_twip_port							
36								
37	pico add extra outputs(\${PROJECT NAME})							
38	endif()							
20	Churry							



Sponsored By

tofClient.c – Add Modified Init UARTs Function

	Client.c
182	
183	
184	//*************************************
185	//* MAIN FUNCTION
186	//*************************************
187	int main()
188	{
189	<pre>stdio_init_all();</pre>
190	<pre>init_uarts();</pre>
191	<pre>if (cyw43_arch_init())</pre>
192	{
193	<pre>DEBUG_printf("failed to initialise\n");</pre>
194	return 1;
195	}
196	cyw43_arch_enable_sta_mode();
197	
198	<pre>printf("Connecting to WiFi\n");</pre>
199	if (cyw43_arch_wifi_connect_timeout_ms(WIFI_SSID, WIFI_PASSWORD, CYW43_AUTH_WPA2_AES_PSK, 30000))
200	{
201	<pre>printf("failed to connect.\n");</pre>
202	return 1;
203	} else
204	{
205	<pre>printf("Connected.\n");</pre>
206	



Sponsored By

tofClient.c - Use Default Serial Port (Enables printf use)

C tof.	c >							
86	//*************************************							
87	//* INITIALIZE UARTS FUNCTION							
88	8 //***********************************							
89	89 void init_uarts(void)							
90	{							
91	<pre>gpio_init(PWREN_PIN);</pre>							
92	<pre>gpio set dir(PWREN PIN, GPIO OUT);</pre>							
93	<pre>gpio_put(PWREN_PIN,0);</pre>							
94								
95	<pre>//gpio_set_function(UART0_TX_PIN, GPI0_FUNC_UART);</pre>							
96	<pre>//gpio_set_function(UART0_RX_PIN, GPI0_FUNC_UART);</pre>							
97	<pre>gpio set function(UART1_TX_PIN, GPI0_FUNC_UART);</pre>							
98	<pre>gpio set function(UART1 RX PIN, GPIO FUNC UART);</pre>							
99								
100	<pre>//uart_init(UART0_ID, 115200);</pre>							
101	uart_init(UART1_ID, 115200);							
102	<pre>//uart_set_hw_flow(UART0_ID, false, false);</pre>							
103	<pre>uart_set_hw_flow(UART1_ID, false, false);</pre>							
104	<pre>//uart_set_format(UART0_ID, DATA_BITS, STOP_BITS, PARITY);</pre>							
105	<pre>uart_set_format(UART1_ID, DATA_BITS, STOP_BITS, PARITY);</pre>							
106	<pre>//uart_set_fifo_enabled(UART0_ID, false);</pre>							
107	<pre>uart_set_fifo_enabled(UART1_ID, false);</pre>							
100								

11



Sponsored By

tofClient.c – Add ToF Init Code to init_uarts

C tof.c	>
110	
111	<pre>irq_set_exclusive_handler(UART1_IRQ, uart1_irq_handler);</pre>
112	
113	<pre>uart_set_irq_enables(UART1_ID, true, false);</pre>
114	<pre>irq_set_enabled(UART1_IRQ, true);</pre>
115	
116	<pre>memset(rxBuf,0xFF,sizeof(rxBuf));</pre>
117	<pre>memset(UART1_RxBuf,0x00,sizeof(UART1_RxBuf));</pre>
118	UART1_RxHead = 0;
119	UART1_RxTail = 0;
120	<pre>busy_wait_ms(100);</pre>
121	<pre>gpio_put(PWREN_PIN,1);</pre>
122	<pre>busy_wait_ms(100);</pre>
123	<pre>setBaud();</pre>
124	<pre>busy_wait_ms(100);</pre>
125	<pre>while(!CharInRing());</pre>
126	<pre>rxBuf[0] = readring();</pre>
127	if(rxBuf[0] != 0x00)
128	{
129	<pre>printf("\r\nautobaud failed!!!\r\n");</pre>
130	<pre>while(1);</pre>
131	}
132	UART1_RxHead = 0;
133	UART1_RxTail = 0;
134	



Sponsored By

C tofCli	ent.c						
221							
222	<pre>while(!state->complete)</pre>						
223	{						
224	cyw43_arch_poll();						
225	<pre>sleep_ms(1);</pre>						
226	<pre>startOneShotSlowMeasure();</pre>						
227	<pre>while(!CharInRing());</pre>						
228	<pre>busy_wait_ms(10);</pre>						
229	bufIndx = 0;						
230	do{						
231	<pre>rxBuf[bufIndx++] = readring();</pre>						
232	<pre>}while(CharInRing());</pre>						
233	txBuf[0] = rxBuf[6];						
234	txBuf[1] = rxBuf[7];						
235	txBuf[2] = rxBuf[8];						
236	<pre>txBuf[3] = rxBuf[9];</pre>						
237	<pre>err_t err = tcp_write(state->tcp_pcb, txBuf, 0x04, TCP_WRITE_FLAG_COPY);</pre>						
238							
239	}						
240	cyw43_arch_deinit();						
241	return 0;						
242							



Sponsored By

M8driver.c – Merge ToF and TCP Client Functionality

C M8driver.c > ... 14 15 uint8 t cmdPkt[9]; uint8 t readModuleStatus[5] = {0xAA,0x80,0x00,0x00,0x80}; 16uint8 t readMeasureResult[5] = {0xAA,0x80,0x00,0x22,0xA2}; 17 uint8 t oneShotAutoDistMeasure[9] = {0xAA,0x00,0x00,0x20,0x00,0x01,0x00,0x00,0x21}; 18 19 uint8 t oneShotSlowDistMeasure[9] = {0xAA,0x00,0x00,0x20,0x00,0x01,0x00,0x01,0x22}; uint8 t oneShotFastDistMeasure[9] = {0xAA,0x00,0x00,0x20,0x00,0x01,0x00,0x02,0x23}; 20 uint8 t continuousAutoDistMeasure[9] = {0xAA,0x00,0x00,0x20,0x00,0x01,0x00,0x04,0x25}; 21 uint8 t continuousSlowDistMeasure[9] = {0xAA,0x00,0x00,0x20,0x00,0x01,0x00,0x05,0x26}; 22 uint8 t continuousFastDistMeasure[9] = $\{0xAA, 0x00, 0x00, 0x20, 0x00, 0x01, 0x00, 0x06, 0x27\};$ 23 24 //*** 25 //* SET BAUD 26 //***** 2 3 5 7 8 **Bytes** 0 4 6 void setBaud(void) 27 28 Head **RW/Address** Register Payload count Payload Checksum Name cmdPkt[0] = 0x55;29 0×00 0x00 0x00 0x00 0x21 0xAA 0x00 0x20 0x01 Data uart putc(UART1 ID,cmdPkt[0]); 30 31 32 //* START 1-SHOT SLOW MEASURE 33 34 11* void startOneShotSlowMeasure(void) 35 36 memcpy(cmdPkt,oneShotSlowDistMeasure,sizeof(oneShotSlowDistMeasure)); 37 for(uint8 t i = 0; i < sizeof(oneShotSlowDistMeasure); i++)</pre> 38 39 uart putc(UART1 ID,cmdPkt[i]); 40 41 14 42




Sponsored By

C tofCli	ent.c	T		1		1					
221		Bytes	0	1	2	3	4	5	6:9	10:11	8
222	<pre>while(!state->complete)</pre>	Name	Head	RW/	Reg	ister	•	load	Payload	Payload	Check
223	{			Address		1	co	unt	Distance	SQ	sum
224	<pre>cyw43_arch_poll();</pre>	Data	0xAA	0x00	0x00	0x22	0x00	0x03	0xAABBCCDD	0x0101	Check
225	<pre>sleep_ms(1);</pre>										sum
226	<pre>startOneShotSlowMeasure();</pre>										
227	<pre>while(!CharInRing());</pre>										
228	<pre>busy_wait_ms(10);</pre>										
229	<pre>bufIndx = 0;</pre>										
230	}ob										
231	<pre>rxBuf[bufIndx++] = readring();</pre>										
232	<pre>}while(CharInRing());</pre>										
233	<pre>txBuf[0] = rxBuf[6];</pre>										
234	<pre>txBuf[1] = rxBuf[7];</pre>										
235	<pre>txBuf[2] = rxBuf[8];</pre>										
236	txBuf[3] = rxBuf[9];										
237	<pre>err_t err = tcp_write(state->tcp_pcb, txBuf, 0x04, TCP_WRITE_FLAG_COPY);</pre>										
238											
239	}										
240	cyw43_arch_deinit();										
241	return 0;									15	5
242	D										










Sponsored By





Sponsored By

Second Se	– 🗆 X	Serial Input/Output Monitor	– 🗆 X
UDP Setup Serial TCP Client TCP Server UDP Test Mode About		File Edit View Configuration	۵.
Received data {00} {00} {00} {00} {00} {00} {00} {00}	Server status Port 8088 Close TEA authorization TEA key	ASCII HEX HEX Image: Clear Terminal Columns Display Data Graph Data Graph Tools Classic Input/Output Input/Output Clear Terminal Viewing Options Data Graph Tools Classic tcp_client_sent 4 AA000022000300000900031E6 tcp_client_sent 4 AA000002200030000090002DE2 tcp_client_sent 4 AA000002200030000090002ADF tcp_client_sent 4 AA000002200030000090002ADF tcp_client_sent 4 AA000002200030000090002ADF tcp_client_sent 4 AA000002200030000090002ADF Tcp_client_sent 4	
Sent data	1: 01020304 3: 090A0B0C 2: 05060708 4: 0D0E0F10	tcp_client_sent 4 AA00002200030000090002EE3 tcp_client_sent 4 AA00002200030000090002EE3 tcp_client_sent 4 AA00002200030000090002FE4 tcp_client_sent 4 AA00002200030000090002EE3	
	Client connection status	tcp_client_sent 4 AA00002200030000090002EE3 tcp_client_sent 4 AA0000022000300000900030E5 tcp_client_sent 4 AA00002200030000090002CE1 tcp_client_sent 4	×.
	2:51:40 PM: All connections clo 2:51:59 PM: 192.168.1.32 Clien 3:01:15 PM: All connections clo ↓ Clients count: 0	41 41 30 30 30 32 32 30 <td< td=""><td>^</td></td<>	^
Send		41 41 30 30 30 32 32 30 <td< td=""><td></td></td<>	
Cursor decode Server settings	wwv.HW-group.com Hercules SETUP utility	ASCII toftof	
TD 125 Redirect to UDP	Version 3.2.8	HEX	Send
		COM6 8N1 115200 R 0 C 0 R52 C 1	Disconnect





Thank you for attending!!!

Please consider the resources below:

- raspberrypi.org
- RP2040 Datasheet
- Raspberry Pi Pico C/C++ SDK
- SEGGER J-Link
- SEGGER Ozone Debugger
- IwIP API Documentation
- JRT Meter Technology







Thank You





Same

