CONTINUING EDUCATION CENTER

Introduction to Real-Time Kernels

Signaling, Inter-Task Communications and Debugging

2013-07-19

Jean J. Labrosse

CEO, **Micriμm**

Outline

- **Signaling a Task**
  - Semaphores
  - Event Flags
- **Inter-task Communications**
- **Debugging kernel-based applications**
  - Output Port
  - DAC output
  - Kernel Aware Debuggers
  - Run-Time Kernel Awareness
  - Trace Tool
- **Summary**

Signaling a Task
(Semaphores)

- **Semaphores are used to signal the occurrence of an event**
  - Either from an ISR or another task

- **Only tasks can wait for events**



Signaling a Task
(Event Flags)



Inter-task Communications
(Message Queues)

- **Message queues are typically used to send actual data to tasks**
- **Messages are typically pointers to the actual data**
  - This avoids copying data
- **ISRs or Tasks can send messages to other Tasks**
- **Only Tasks can receive messages**



Inter-task Communications
(Message Queues)




```
RPM_ISR()
{
  Read Input Capture;
  Post Counts;
}
```

```
RPMTask()
{
  while (1)
    Wait for message from ISR (with timeout);

    if (timed out)
       RPM = 0;
    else {
       DeltaCounts     = Counts
                       - PreviousCounts;
       PreviousCounts = Count;
       RPM             = 60 * Fin / DeltaCounts;
    }
    Compute average RPM;
    Check for overspeed/underspeed;
    Keep track of peak RPM;
}
```

Debugging with Kernels
(Debugger)

```
static  void  PowerMeter_Task (void *p_arg)
{
    OS_ERR       err;
    CPU_INT16U   i;
    CPU_INT16U   current_phase_angle;
    CPU_FP32     v2;
    CPU_FP32     i2;
    CPU_FP32     sum_v2;
    CPU_FP32     sum_i2;
    CPU_FP32     sum_p;


   (void)p_arg;

    while (DEF_TRUE) {                          /* Task body, always written as an infinite loop.    */
        OSTimeDlyHMSM(0, 0, 0, 200,
                      OS_OPT_TIME_HMSM_STRICT,
                      &err);

        PowerMeter_PowerFactor = (CPU_FP32)cos(PowerMeter_PIdiv180 * (CPU_FP32)PowerMeter_PhaseAngle);

        sum_v2                 = (CPU_FP32)0.0;
        sum_i2                 = (CPU_FP32)0.0;
        sum_p                  = (CPU_FP32)0.0;
        for (i = 0; i < 360; i++) {
            current_phase_angle                         = (i + PowerMeter_PhaseAngle) % 360;
            PowerMeter_VoltageTbl[i]                    = PowerMeter_VoltagePeak   * PowerMeter_SineTbl[i];
            PowerMeter_CurrentTbl[current_phase_angle] = PowerMeter_CurrentPeak   * PowerMeter_SineTbl[i];
            v2                                          = PowerMeter_VoltageTbl[i] * PowerMeter_VoltageTbl[i];
            i2                                          = PowerMeter_CurrentTbl[i] * PowerMeter_CurrentTbl[i];
            sum_v2                                     += v2;
            sum_i2                                     += i2;
            sum_p                                      += PowerMeter_VoltageTbl[i] * PowerMeter_CurrentTbl[i];
        }

        PowerMeter_VoltageRMS      = (CPU_FP32)sqrt(sum_v2 / (CPU_FP64)360.0);
        PowerMeter_CurrentRMS      = (CPU_FP32)sqrt(sum_i2 / (CPU_FP64)360.0);
        PowerMeter_PowerApparent   = PowerMeter_VoltageRMS * PowerMeter_CurrentRMS;
        PowerMeter_PowerActive     = sum_p  / (CPU_FP64)360.0;
    }
}
#endif
#endif
```

Debugging with Kernels
(Kernel Aware Debugger)

µC/OS-III Task List

#	Task Name	Prio...	State	Pending On Object	Pending On	CPU U...	Bar Graph	Context Swit...	Stack Poi...	Stack Size
0	Temp Ctrl	8	Delayed			0.02%		93	0x20009FEC	80
1	RPM Timer Reload	4	Delayed			0.01%		93	0x2000AEEC	80
2	RPM	5	Pending with Timeout	Task Message Queue	Task Q	0.02%		169	0x2000AD8C	80
3	Power Meter	8	Delayed			0.00%		61	0x2000A474	80
4	ECG Waveform	8	Delayed			0.16%		932	0x2000A6C0	80
5	Dimmer	8	Delayed			0.00%		46	0x2000A230	80
6	Probe TCPIP	2	Pending	Semaphore	Net Sock Rx ...	0.00%		0	0x200076E4	300
7	Net IF Tx Dealloc Task	5	Pending	Task Message Queue	Task Q	0.00%		0	0x20006058	100
8	Net IF Rx Task	7	Pending	Task Message Queue	Task Q	0.00%		0	0x20005EC8	300
9	Net Tmr Task	6	Delayed			0.13%		93	0x200097E0	150
10	Start	2	Delayed			0.06%		93	0x20009D84	175
11	uC/Probe-Term Trace Task	12	Delayed		Task Sem	0.03%		93	0x20005860	128
12	uC/Probe-Term Cmd-Line Tx Task	11	Pending	Task Semaphore	Task Sem	0.00%		0	0x2000555C	128
13	uC/Probe-Term Cmd-Line Rx Task	10	Delayed			0.01%		93	0x20005288	128
14	uC/OS-III Timer Task	17	Pending	Task Semaphore	Task Sem	0.02%		93	0x2000B374	75
15	uC/OS-III Stat Task	18	Delayed			0.35%		93	0x2000B12C	75
16	uC/OS-III Tick Task	16	Pending	Task Semaphore	Task Sem	1.87%		9134	0x2000B268	75
17	uC/OS-III Idle Task	19	Ready			97.28%		9243	0x2000BDBC	50

Debugging with a Kernel
(Output Port)





Debugging with a Kernel
(DAC Output)



Debugging with Kernels
(Run-Time Kernel Awareness)



Task(s)							Performance				Task Stack				Task Queue				
Item	Name	Priority	State	Pending On Object	Pending On	Ticks Remaining	CPU Usage	CtxSwCtr	Interrupt Disable Time (Max)	Scheduler Lock Time (Max)	#Used	#Free	Size	Stack Usage	Entries	Entries (Max)	Size	Msg Sent Time	Msg S Tim (Ma
0	Temp Ctrl	8	Delayed			100	2.00 %	86	3.65	0.00	33	47	80	41.25 %	0	0	10	0.00	
1	RPM Timer Reload	4	Delayed			100	0.01 %	86	3.65	0.00	25	55	80	31.25 %	0	0	10	0.00	
2	RPM	5	Pending + Timeout	Task Message Queue	Task Q	1,000	0.05 %	145	7.18	0.00	34	46	80	42.50 %	0	0	10	14.14	1
3	Power Meter	8	Delayed			200	0.00 %	44	3.61	0.00	33	47	80	41.25 %	0	0	10	0.00	
4	ECG Waveform	8	Delayed			10	0.16 %	881	3.75	0.00	29	51	80	36.25 %	0	0	10	0.00	
5	Dimmer	8	Delayed			200	2.17 %	44	3.33	0.00	33	47	80	41.25 %	0	0	10	0.00	
6	Probe TCPIP	2	Pending	Semaphore	Net Sock Rx Q #1	0	0.00 %	0	0.00	0.00	104	196	300	34.67 %	0	0	0	0.00	
7	Net IF Tx Dealloc Task	5	Pending	Task Message Queue	Task Q	0	0.00 %	0	0.00	0.00	35	65	100	35.00 %	0	0	20	0.00	
8	Net IF Rx Task	7	Pending	Task Message Queue	Task Q	0	0.00 %	0	0.00	0.00	35	265	300	11.67 %	0	0	20	0.00	
9	Net Tmr Task	6	Delayed			51	0.13 %	88	3.32	0.00	42	108	150	28.00 %	0	0	0	0.00	
10	Start	2	Delayed			100	0.06 %	88	3.65	0.00	86	89	175	49.14 %	0	0	10	0.00	
11	uC/Probe-Term Trace Task	12	Ready		Task Sem	0	0.01 %	89	3.69	0.00	32	96	128	25.00 %	0	0	0	0.00	
12	uC/Probe-Term Cmd-Line Tx Task	11	Pending	Task Semaphore	Task Sem	0	0.00 %	0	0.00	0.00	32	96	128	25.00 %	0	0	0	0.00	
13	uC/Probe-Term Cmd-Line Rx Task	10	Delayed			17	0.01 %	89	3.25	0.00	25	103	128	19.53 %	0	0	0	0.00	
14	uC/OS-III Timer Task	17	Pending	Task Semaphore	Task Sem	0	0.02 %	90	3.50	4.47	36	39	75	48.00 %	0	0	0	0.00	
15	uC/OS-III Stat Task	18	Delayed			100	0.35 %	90	3.25	0.00	32	43	75	42.67 %	0	0	0	0.00	
16	uC/OS-III Tick Task	16	Pending	Task Semaphore	Task Sem	0	1.84 %	8,938	15.92	0.00	28	47	75	37.33 %	0	0	0	0.00	
17	uC/OS-III Idle Task	19	Ready			0	92.49 %	8,461	3.64	0.00	20	30	50	40.00 %	0	0	0	0.00	

Debugging with Kernels
(Kernel Trace Tool)



Summary

- **A kernel is software that manages the time of a CPU**
  - A kernel is a 'Subset' of an RTOS
  - Allows multitasking – you split your application into 'Tasks'
  - Each task is assigned a 'Priority'
  - Provides services to your application
    - Semaphores, Queues, Timers, Time Management and so on
- **Most kernels are 'Preemptive'**
  - The kernel will always run the highest-priority task that is ready-to-run
- **A Task is an Infinite Loop**
  - Each task needs to wait for an event to occur
  - Each task has its own stack, can access data and I/O devices

Summary

- **ISRs are more important than tasks**
  - ISRs can be kernel or non-kernel aware
- **Kernels typically require a Tick ISR**
  - Provides time delays and timeouts
  - This is NOT mandatory
- **Your application might share resources**
  - You need to protect those with Mutexes

Conclusion

Thank you for attending

Hope you found this class useful

www.micrium.com